



- 1 – 5 : preset edition. Press same button again or (button + encoder) to navigate through the pages of each button.
- 6 : change current instrument or 'back' in menu mode
- 7 : enter menu mode (in menu mode 6 become back button)
- 8 : change values
- 9 : analog volume

Edit

- 1 : engine, Modulation, Mixer, Arpeggiator, Filter
- 2 : operator from 1 to 6
- 3 : for operator selected in 2 : waveform, envelope
- 4 : matrix row from 1 to 12
- 5 : LFO and modulators : lfo1-3, env1-2, step seq 1-2, midi note modulator
- 5 + 7 (or 8 if clickable) : performance

Menu

- You enter menu after pressing 7
- 6 is the Back button. When at the top, returns to edit mode.
- . Load > Bank, Combo, DX7, Randomiser
 - . Save > Bank, Combo, Default combo
 - . Tools > settings, create, rename, Scala
- Randomizer** : encoder to modify what is changed, 1-5 button to trigger new random
- Settings**: Enc 1 changes setting, Enc 2 changes value. Press 7 again to save.

Tips

- Hold 1 + 7 : show current FM algo
- Hold 1 + 6 : show current IM
- Mix, pan, env edit : hold 3 to modify all other carrier/modulator operators at the same time
- Hold 1, 2, 4, 5, 6 and turn any encoder to navigate quickly through the pages
- Hold any key while powering the preenfm enter bootloader to flash new firmware.
- Hold 6 + encoder : modify value 10 times faster
- Hold 7 + encoder : reset value
- Hold 1 and press 2 : go to main engine page.
- Hold 6 + 1-5 : play note